

# Model 950


2" Model Depicted Below

## Notes:


1. Index numbers are listed in numerical order on the **Parts Guide** with corresponding part description, part numbers, and list prices.
2. Circular index numbers indicate that the part can be purchased separately.
3. Triangular index numbers indicate that the part is available as part of a sub-assembly or repair kit.

## Sub-Assemblies & Repair Kits



Repair Kits (all rubber & fiber parts) -  195

Diaphragm Assembly -  196

Top Assembly -  197

Flow Control Assembly -  198

Solenoid Assembly -  17



Index No.	Part Name/Discription		3/4"	1"	1 1/4"	1 1/2"	2"	2-1/2"	3"
2	Solenoid Retainer Nut	Part No.	16003	16003	16003	16003	16003	16003	16003
		Price (\$)	1.16	1.16	1.16	1.16	1.16	1.16	1.16
3	Solenoid Farme		16009	16009	16009	16009	16009	16009	16009
			4.14	4.14	4.14	4.14	4.14	4.14	4.14
4	Solenoid Coil		16008	16008	16008	16008	16008	16008	16008
			13.37	13.37	13.37	13.37	13.37	13.37	13.37
6	Solenoid Stem and Plunger Assembly		16010-2A	16010-2A	16010-2A	16010-2A	16010-2A	16010-2A	16010-2A
			15.45	15.45	15.45	15.45	15.45	15.45	15.45
17	24 VAC Solenoid Assembly (950, 950A, 950SD)		16200	16200	16200	16200	16200	16200	16200
			27.84	27.84	27.84	27.84	27.84	27.84	27.84
45	Flow Control Cross Handle			16034	16035	16035	16035	16035	16035
				7.88	5.54	5.54	5.54	5.54	5.54
47	Flow Control Stem (includes cleaning rod and o-ring)		20006-A	16081	16004-1	16004	16004	19000	19000
			5.54	6.46	15.82	13.31	13.31	41.85	41.85
53	Drain Cock (includes o-ring) 950, 950A, 950DW		15013	15013	15013	15013	15013	15013	15013
			4.48	4.48	4.48	4.48	4.48	4.48	4.48
62	Diaphragm Cap Bolts		16042	16042	16041	16041	16041	16041	16041
			1.01	1.01	1.01	1.01	1.01	6.06	6.06
68	Diaphragm Spring		16050	16051	16051	16052	16052	19017	19017
			1.04	1.42	1.42	1.68	1.68	2.32	2.32
69	Diaphragm Shaft w/insert		16013A	16014A	16015A	16016A	16016A	19005-2	19005-2
			29.01	29.01	29.01	29.01	29.01	31.64	31.64
81	Diaphragm		16055	16056-A	16057RW	16058	16058	400028	400028
			6.33	8.57	12.13	16.81	16.81	58.53	58.53
195	Repair Kits (all rubber and fiber parts)		17308	17309	17310	17311	17312	17313	17313
			10.81	13.97	16.48	24.81	26.87	87.72	87.72
196	Diaphragm Assembly (950, 950A, 950SD)		16211	16212	16213	16214	16215	16216	16216
			24.65	32.11	40.61	73.32	79.32	294.47	294.47
197	Top Assembly (950, 950A)		16201	16202	16203	16204	16205	16206	16206
			48.64	67.89	87.79	97.02	97.02	290.75	290.75
198	Flow Control Assembly		16206	16207	16208	16209	16209	16221	16221
			12.51	11.34	21.68	14.11	14.11	33.38	33.38

Like us on Facebook!

